

System Setup			
Number of Device Connections	Unlimited	Up to 80	Up to 40
Number of Client Workstations	Unlimited	Unlimited	Unlimited
Number of NVR-AS Connections	Unlimited	Unlimited	Unlimited
Real Time Monitoring			
Live Video	✓	✓	✓
Dynamic Profile Switching	✓	✓	✓
PTZ Control and Presets, Client-Side Dewarping	✓	✓	✓
Control Center Mobile	✓	✓	✓
Audio - Live	✓	✓	✓
Customizable Video Pane Layouts	✓	✓	✓
Sequences, Salvos and Guard Tours	✓	✓	
Maps	✓	✓	
Webpages	✓	✓	
Connect to Third Party Systems*	✓	✓	
Support for IndigoVision's LPR powered by InnoWare*^	✓	✓	
Pursuit Mode	✓	✓	
Support for CyberVigilant® in Camera	✓	✓	
Connect to CyberVigilant®*	✓		
ONVIF PTZ Priority	✓		
Integrated to FrontLine Video	✓		
Connect to Video Wall*	✓		
Alarm Management			
Alarm Actions	✓	✓	✓
Alarm Groups	✓	✓	✓
Alarm Escalation	✓	✓	
Analytics Overlays	✓	✓	✓**
Detector - Fault	✓	✓	✓
Detector - Digital Input	✓	✓	✓
Detector - Basic Analytics	✓	✓	✓
Detector - Advanced Analytics	✓	✓	
Detector - External	✓	✓	
Detector - CyberVigilant in Camera	✓	✓	
Detector - Double Knock	✓		
Detector - Unhandled Alarm	✓		
Post Event Monitoring			
Playback (Synchronized and Unsynchronized)	✓	✓	✓
Thumbnails	✓	✓	✓
Export Recordings and Snapshots	✓	✓	✓
Recording (Continuous and Scheduled)	✓	✓	✓
Flexible Retention Times	✓	✓	✓
Protected Recordings	✓	✓	✓
Audio - Recording	✓	✓	✓
Bookmarks	✓	✓	✓
Edge Storage Retrieval	✓	✓	✓
NVR Footage Retrieval	✓	✓	
Artificial Intelligence Powered By BriefCam*	✓		
Data Record Management	✓		
Failover Recording and Redundancy	✓		
Automatic NVR Switching	✓		
System Administration & Security			
User Management and Permissions	✓	✓	✓
Audit Log	✓	✓	✓
System Monitoring	✓	✓	✓
Digital Watermarking on Export	✓	✓	✓
Digital Watermarking on Recording	✓	✓	✓
Windows User Authentication	✓	✓	
Segmented Databases	✓		

* Purchase product to be connected separately. ** UAD overlays are not available in IndigoLite.

^ Support for Integrated Data Records in LPR requires IndigoUltra® license.