




IndigoVision



Lenel OnGuard

The IndigoVision Lenel OnGuard Integration Module allows a bi-directional flow of events and alarms between Lenel's OnGuard system and IndigoVision's video security solution.

Trigger live video, move PTZ cameras, start recordings and send notification emails automatically in IndigoVision's Control Center software from events generated in the Lenel OnGuard system - dramatically improving operator response time.

Using IndigoVision's Control Center software, actions in the Lenel OnGuard system can also be executed through the 'Output Actions' commands; e.g. locking/unlocking doors, signing out visitors etc.

Key Features

CONTROL CENTER
ACTING AS FRONT END



THIRD PARTY SYSTEM
ACTING AS FRONT END



Product Codes

	Product Code
Lenel OnGuard Integration Module, Software License Key*	317400

*supported from v2.2 of the Integration Module.



Specifications

General Specifications	
Lenel System Software Requirements	Lenel OnGuard 7.5 or 7.4. Lenel DataConduIT (OpenIT) v5.12 or later license
IndigoVision System Software Requirements	IndigoVision Lenel OnGuard Integration Module v2.3. Compatible with SMS4™ r2 onwards/Control Center v11.0 or later
Event and Alarm Integration Capability	Bi-directional flow of events and alarms between Control Center and the Lenel OnGuard system.
Manually Control Actions within the Third Party System	Set relays in Control Center can create specific events in the Lenel OnGuard system such as turning the alarm status of a reader on or off or changing the access state of a door from i.e. locked or unlocked.
Integration Server Specification	PC requirements for Lenel OnGuard vary depending on the size of the access control system and the database software being used. Refer to Lenel OnGuard documentation for advice on machine specifications. The IndigoVision Lenel OnGuard Integration Module may run on the same PC as Lenel OnGuard or on a separate PC. There are no extra requirements on the specification of the PC due to the IndigoVision software. NOTE:The Integration Module is a licensed product. A correctly licensed USB dongle or software license key must be present on the platform running the Integration Module. The Integration Module should not be run on the same server as certain Integration Modules.
Supported Products	Area Access Manager, Biometrics and Smart Cards, ID CredentialCenter, Fire and Intrusion, Visitor
Certifications	IndigoVision is a member of the Lenel OpenAccess Alliance Program. The IndigoVision Lenel OnGuard Integration Module is certified by Lenel to allow integration between Control Center and OnGuard 7.5 or 7.4.
Supported Operating Systems	Microsoft® Windows Server 2016®, Microsoft® Windows Server 2012 R2, Microsoft® Windows Server 2012®, Microsoft® Windows Server 2008 R2®, Microsoft® Windows 10® (64-bit), Microsoft® Windows 8.1® (64-bit), Microsoft® Windows 7® (64-bit)

Lenel OnGuard Events and IndigoVision Actions Supported

Examples of Supported Events
Access granted
Invalid access level
Door forced open
Cabinet tamper active
Cabinet tamper restored
Anti-passback violation
Access zone shunt
Intercom system event
Door held open
Operator event
Card event
Card error
Security breach
Tamper
Wrong PIN
Input masked
Activate output

Examples of Supported Actions
PTZ Camera moves to Preset
Video from one or more cameras displayed on operator's PC
Notification email sent
Recording of any camera started
CCTV site map pops up with event source highlighted
Two way audio connection established so operator can listen and talk to the source of the event
Relay triggered action initiated e.g. door opens or lights turn on